



This is what your pump should look like after you take the bubble wrap off.

Note: Usually the muffler is in the same box as the gauge.



First, take red cap out of the front of the "cross fitting", thread the "moisture trap assembly" in. Make sure to thread this in clockwise. Use a wrench to SNUG. Please do not overtighten!!



Once the moisture trap assembly is tight, it should look like this.



Second, take red cap out of the “outlet” and thread in your muffer. It should look like this when complete.



Finally, take the 1/4 “ red cap out of the top of you cross fitting, and thread in your vacuum gauge. Your pump should look like this when its complete.

Note:

Your 1/2” vacuum hose will attach to the brass hose barb that’s pictured.

The black handled “on/off” is for if an emergency were to occur, such as too much milk or wash water in the bucket. Do NOT let any liquid get past your moisture trap!

GAST MANUFACTURING 1023

Brought To You By:

Schmitzer Farm Service LLC